

CONCRETE SURROUND FACT SHEET

NOTE: Not adhering to these guidelines could result in voiding some warranties on your pool
Please print this Fact Sheet for your Concreter or Landscaper

WHEN TO POUR

- **14 days** minimum after the shell is poured should elapse before any surround concreting is attempted

STARTER BAR OR PINS

Starter bars or pins are steel reinforcing rods installed into the pool's beam and these are tied to the surrounds steel reinforcing which insures minimal vertical movement of the surround concrete. Starter bars

- Must be done in the beam of the pool
- Must be 100mm from the top of the pool shell (not the coping tile)
- Must not be more than 50mm in depth into the pool beam
- No drilling must be done to the pool shell

EXPANSION JOINT

- A 10mm expansion joint such as Able Flex **MUST** be used between pool shell/beam & surround concrete

DIAGRAM

